

Target Models

UB-E04 Technical Reference Guide		
TM-H2000	TM-J7500/J7600	TM-L90
TM-H5000	TM-J9000/J9100	TM-U220
TM-H5000II	TM-T20	TM-U230
TM-H6000II	TM-T70	TM-U325
TM-H6000III	TM-T88III	TM-U675
TM-H6000IV	TM-T88IV	TM-U590
TM-J2000/2100	TM-T88V	
TM-J7000/J7100	TM-T90	